Validation of Acetone using SKC Passive Sampler 575-002



SKC Inc. 863 Valley View Road Eighty Four, PA 15330

Contents

Abstract		1	
Importance of	f Validation of Passive Samplers	2	
Summary of M	NIOSH Validation Protocol	4	
Bi-Level Vali	dation	6	
Comments on	the Relationship Between the NIOSH and		
CEN Diffusi	ve Sampler Evaluation Protocols	8	
Scope of the I	Method	10	
Background		11	
Analytical Re	covery	12	
Sampling Rat	e and Capacity	13	
Reverse Diffusion			
Storage Stability			
Factorial Resu	ılts	16	
Factorial Sum	ımary	17	
Temperature l	Effects	18	
Accuracy and	Precision	19	
Appendix A.	Atmosphere Generation Apparatus	20	
Figure 1.	Atmosphere Generation Apparatus	21	
Figure 2.	Analytical Instrument	22	
Abbreviations	s, Trademarks	23	
Deferences		24	

Research Report

Validation of Acetone using SKC Passive Sampler 575-002

Abstract

A sampling method for Acetone in air has been validated for concentration levels from 75 to 1500 ppm and for exposure times from 7.5 minutes to 12 hours. The 575-002 passive sampler used has a sample medium of Anasorb® 747. Desorption was with carbon disulfide and analysis by gas chromatography with flame ionization detection.

The analytical recovery over the range of 75 to 1500 ppm (1.4 to 28 mg) was 90.2% with a relative standard deviation (RSD) of 3.4% under high humidity; under dry conditions the recovery was 94.1% with an RSD of 8.6%.

The sampling rate is 15.2 ml/min (RSD 10%) for sampling from 1 to 8 hours. The rate is consistent up to 10 hours. Samples can be taken from 10 to 40° C.

NOTE: For STEL sampling, 7.5 to 30 minutes, a sampling rate of 20.3 ml/min (RSD 8.9%) should be used.

Storage stability at freezer temperature (-8° C) showed no significant loss in recovery after 14 days. Significant sample loss is observed when samplers are stored for 2 weeks at room temperature. Room temperature storage is not recommended.

A full validation of Acetone was done according to NIOSH Protocol.¹

Authors

Michelle Kimberland Amy Fiore Linda S. Coyne Martin Harper

Compiled by Martin Harper, Ph.D.

SKC Inc.

863 Valley View Road Eighty Four, PA 15330 USA

1

Publication No. 1303 Rev 230825

Importance of Validation of Passive Samplers

There are distinct differences between a passive sampler and a sample tube.

The most important difference is that a passive sampler does not have a foolproof back up section that guarantees that all the chemical hazard has been collected and there is a true and total measure of the worker exposure.

Secondly, the sorbent media is exposed to the external environment and this poses problems not associated with a sample tube where the air sample passes into the sample tube directly contacting the sorbent media. That is why it is critical to use a strong sorbent medium in passive samplers to assure complete capture and retention.

Therefore, for compliance purposes a passive sampler must be laboratory tested and validated under worst case field conditions for all factors that affect sampling accuracy as well as interaction between affects.

NIOSH has laid out a rigorous and complete validation protocol to assure that the sample collected is a complete and true measure of worker exposure. The following are the factors that the NIOSH protocol addresses:

Factors That Affect Complete Sample Uptake & Retention

Chemical Hazard Concentration Temperature

Time of Exposure Humidity

Sorbent Capacity Interfering Chemicals

Sorbent Strength Reverse Diffusion from Sorbent Surface

Wind Velocity Sampler Orientation

Interaction of Any of the Above Factors

Validation by NIOSH protocol assures that the sample results are a true and total measure of worker exposure.

SKC Validation follows the NIOSH Validation Protocol. Certain experiments may have been modified for practical reasons, or to provide more rigorous tests.

User Responsibility

The sampler manager should be a professional trained in air sampling and aware of the limitations and advantages of the method being used. It is also very helpful if they have a working relationship with the analytical techniques being used and the requirements of record keeping.

In accordance with ASTM D6346-98 and ANSI 104-1998 standards, use of samplers outside the range of conditions used in these validation tests does not assure accurate results and is not recommended. It is the user's responsibility to determine whether the conditions of the sampling site fall within the range tested. For bi-level validations it can be assumed that the applicable range is that used for testing the lower member of the homologous series.

Workers should be trained in the use of the equipment. In collecting the sample, care should be taken in the location of the sampler on the worker. It is to be openly exposed near the breathing zone. Exact times of exposure must be recorded. No moisture condensation should occur on the sampler. Workers should not be allowed to touch the sampler as they may transfer contamination. Particular attention must be paid to environments where liquid aerosols may be present, since droplets of liquid solvent on the sampler face will invalidate the sample. Any other field conditions outside of the limits used in the NIOSH protocol, such as extreme temperatures or stagnant air conditions which might affect the sampler operation should be recorded.

Good laboratory practice must be followed. Follow the operating instructions for the desorption time needed for complete desorption. Use only the correct desorption instrument. If gas chromatography is used as the analysis method, base line separation should occur with the chemical hazard of interest and proper instrument calibration procedures used.

NIOSH or OSHA analytical methods should be used.

Summary of NIOSH Validation Protocol¹

Characteristic	Experimental Design		Interpretation of Results
1. Analytical Recovery	Spike 16 samplers, 4 at ea levels (0.1, 0.5, 1.0 & 2.0 about 12 h and analyze.		For the higher 3 levels require \geq 75% recoveries with $S_r \leq 0.1$.
2. Sampling Rate and Capacity	Expose samplers (4 per time period) for 1/8, 1/4, 1/2, 1, 2, 4, 6, 8, 10 & 12 h to 2 x STD, 80% RH and 20 cm/s face velocity. Plot concentration vs. time exposed. Determine MRST and SRST.		Verify sampling rate. State useful range at 80% RH & 2 x STD. Capacity - sample loading corresponding to the downward break in conc. vs time curve from constant concentration. SRST - time linear uptake rate achieved. MRST-0.67 x capacity (1 analyte) MRST-0.33 x capacity (Multi-analyte)
3. Reverse Diffusion	Expose 20 samplers to 2 x MRST. Remove and and Expose others to 80% RH remainder of MRST.	alyze 10 samplers.	Require \leq 10% difference between means of the two sampler sets at the 95% CL.
4. Storage Stability	Expose 3 sets of samplers (10 per set) at 80% RH, 1 x STD, and 0.5 x MRST. Analyze first set within 1 day, second set after 2 weeks storage at about 25° C, third set after 2 weeks storage at about 5° C.		Require ≤ 10% difference at the 95% CL between means of stored sampler sets and set analyzed within 1 day.
5. Factor Effects	Test the following factors Use a 16 -run fractional fa samplers per exposure) to factors.	ctorial design (4	Indicate any factor that causes a statistically significant difference in recovery at the 95% CL. Investigate further to characterize its effect.
	Factor analyte concentration exposure time face velocity relative humidity interferant sampler orientation	Test Levels 0.1 & 2 x STD SRST & MRST 10 & 150 cm/s 10 & 80% RH 0 & 1 x STD parallel & perpendicular (to air flow)	
6. Temperature Effects	Expose samplers (10 per t 10, 25, & 40° C for 0.5 x 1		Define temperature effect and verify correction factor, if provided.
7. Accuracy and Precision	Calculate precision and bias for samplers (10 per conc. level) exposed to 0.1, 0.5, 1 & 2 x STD at 80% RH for ≥ MRST. Use data from previous experiments.		Require bias within \pm 25% of true value at 95% CL with precision $S_r \le 10.5\%$ for 0.5, 1, & 2 x STD levels.

Summary of NIOSH Validation Protocol (cont.)

Characteristic	Experimental Design	Interpretation of Results
8. Shelf Life	Observe samplers throughout evaluation for changes in blank values, physical appearance, etc. Test samplers from more than one lot, if possible.	Note shelf storage time at which changes begin to occur. Indicate whether correctable or not.
9. Behavior in the Field	Consider problems not predictable from laboratory experiments.	Record temperature, humidity, air velocity, other contaminants, etc.
Area Sampling:	Expose passive samplers and independent method samplers (13 each) to the same environment.	Calculate precision and bias. Compare with laboratory results.
Personal Sampling:	Conduct personal sampling with ≥ 25 sampler pairs. Place pairs of passive samplers and independent samplers on the same lapel of each worker.	Calculate bias. Compare with area sampling and laboratory results

Bi-Level Validation (previously designated by SKC as 5B)

Validation of passive samplers is essential to ensure accurate determination of airborne chemical levels. To assist manufacturers and users, the National Institute for Occupational Safety and Health (NIOSH), the Health and Safety Executive (HSE)², and the Comité Européen de Normalisation (CEN)^{3,4} have developed comprehensive protocols for the validation of passive samplers.

Bi-level validation can also be used to assure a sample that gives the total and complete exposure to a chemical hazard.

Bi-level validation is only for a series of chemically related compounds, i.e., members of a homologous series. Bi-level validation includes a full protocol validation on key compounds followed by a partial validation on other members of the series.

The concept of a bi-level validation of chemically related compounds for a given sorbent and sampler design is based on the following premises and has been studied by Guild et al.⁵

- Full validation by NIOSH, HSE, or CEN Protocol of a lower member of the series is essential to assure accurate, routine sampling under all field conditions without the need for error-corrective measures.
- 2. Capacity and retentivity are directly related to the affinity of a sorbent for a specific chemical. For a series of chemically related compounds, the affinity of a sorbent for a particular member compound will increase with the molecular weight and boiling point of the member. If a sorbent is suitable for collecting a low molecular weight member of the series, it will be suitable for the higher molecular weight members of the series as well.
- 3. For chemically stable compounds, sample loss by reverse diffusion and loss during storage are inversely related to the affinity of the sorbent for the adsorbate. Therefore, compounds with higher molecular weights and boiling points will exhibit less loss by reverse diffusion and storage. Again, if a sorbent is suitable for a member with a lower molecular weight and boiling point, it will be suitable for the higher members.
- 4. The linearity of uptake with time is also a function of sorbent affinity and capacity. Uptake becomes increasingly linear as the molecular weight and boiling point increases and the sample load decreases. (Protocol validation requires study of concentrations ranging from 0.1 to 2.0 x the permissible exposure limit.)

Bi-Level Validation (cont.)

- 5. Temperature affects the accuracy of passive samplers in two different ways; the relation of temperature to adsorption affinity and the relation of the molecular diffusion of the sample to the sampler.
 - a. It is well known that the affinity of a sorbent for a chemical decreases with increasing temperature. If the sorbent has adequate affinity for a low molecular weight member of the series at 40° C (the maximum temperature tested under protocol), it will also be adequate at lower temperatures, and for higher molecular weight members of the series.
 - b. The effects of temperature on sample uptake follow established mathematical relationships and are not significant compared to other random sampling errors.
- 6. The effects of humidity because of competition or modification of sorbent affinity will be most pronounced for lower members of the series.
- 7. Adsorption affinity decreases with the mass adsorbed. Therefore, the "key" member chosen for full validation should have a high PEL relative to the other members of the series.
- 8. Air velocity and sampler-orientation effects are functions of sampler design and will be similar for all compounds.
- 9. If all the factors affecting sampling accuracy improve with increasing molecular weight and boiling point and there are no interacting effects of these parameters with a lower member of the series, then there will be no interacting effects with higher members.
- 10. The accuracy of a sampler is determined by its bias and precision. For most passive samplers, the bias is the result of the deviation of the calculated sample rate from the actual rate. By determining the sample rate under known conditions at 1 PEL, the bias is reduced to zero. Therefore, measured sample rates should be determined for all compounds.
- 11. The precision of a sampler is a function of the consistency of sampler manufacture and the analytical procedures in the laboratory.
- 12. Analytical recovery tends to decrease with increased sorbent affinity and is a function of the chemical compound, the concentration, and the sorbent. Therefore, analytical recovery should be determined for every compound over the concentration range of 0.1 to 2.0 PEL, as recommended by protocol.

Conclusion: The above premises have been verified, peer reviewed and published.⁵ Therefore, Bi-Level validation (5B) is an excellent way to assure accurate performance of a passive sampler for higher members of a homologous series.

Comments on the Relationship Between the NIOSH and CEN Diffusive Sampler Evaluation Protocols

The Comité Européen de Normalisation (CEN) is engaged in writing standards for air sampling equipment which include the limitations on precision and accuracy (EN 482) and the required performance tests. In the case of passive samplers the relevant performance test standard is yet to be published, but draft copies are available (prEN 838).

The precision and accuracy requirements in EN 482 are based on the use that will be made of the results, principally either for problem identification or compliance purposes. The standard for compliance purposes is a combined precision and accuracy of less than 30%, which is a looser standard than the 25% in the NIOSH protocol.

The performance tests are closely related to those in the NIOSH protocol, as might be expected, since they are trying to confirm the performance of the samplers over a similar range of environmental conditions. As in the NIOSH protocol there are tests for desorption efficiency, uptake rate at different concentrations and for different time-periods, reverse diffusion, storage stability, wind velocity and orientation, humidity, temperature, and the presence or absence of interferences. As in the NIOSH protocol these factors are normally tested using a "high" and a "low" measure, whether alone or in combination. Since there is little difference between workplace conditions in the U.S.A. and Europe, these "high" and "low" conditions are very similar in the two protocols. In general, the NIOSH test provides the more stringent conditions (e.g. 7.5 minutes up to 12 hours in the NIOSH uptake rate experiment versus 30 minutes and 8 hours in the CEN equivalent). In addition, for the majority of the experiments, the NIOSH protocol requires more samples to be taken for each data point (typically 10 rather than 6). The reverse diffusion test is one test that might be considered significantly different, and a paper showing that the results of the tests are actually comparable has been submitted for publication.⁶

In addition, the CEN protocol requires tests for shelf-life and packaging integrity that have been carried out for one analyte (n-Hexane) only. The 575 Series passive sampler successfully passed these tests.

For the reasons given above, SKC considers the validations presented in these research reports to be at least sufficient to meet the requirements of the European Standards prEN 838 and EN 482 for compliance monitoring. This conclusion is supported by a detailed comparison which has been submitted for publication.⁷

The CEN protocol supports the Bi-level theory of validation.

SHELF-LIFE STUDY ON 575 SERIES PASSIVE SAMPLERS

Protocol: 4 expired and 2 unexpired 575-001 samplers were exposed to an atmosphere 100 ppm n-Hexane (2 X PEL) at 80% relative humidity (25° C) for 30 minutes, and then analyzed. Study was conducted August 1995.

Results:

Calculated atmosphere concentration: 106 ppm

Gas sample analysis concentration: 102 ppm (RSD = 7.0%)Sorbent tube analysis concentration: 115 ppm (RSD = 3.2%)

Sampler analysis concentration:[◊]

Sampler expired 12/92: 106 ppm

Sampler expired 4/94: 106 ppm

Sampler expired 10/94: 108 ppm

Sampler expired 10/94: 110 ppm

Sampler unexpired (7/96): 100 ppm

Sampler unexpired (7/96): 100 ppm

Conclusion: Samplers will perform as expected up to their expiration date.

PACKAGING INTEGRITY STUDY ON 575 SERIES SAMPLERS

Protocol: 6 575-001 samplers in unopened Tedlar® pouches were exposed to an atmosphere of 100 ppm n-Hexane (2 X PEL) at 80% relative humidity (25° C) for four hours, and then opened and analyzed.

Results:

Calculated atmosphere concentration: 103 ppm

Gas sample analysis concentration: 104 ppm (RSD = 8.7%)Sorbent tube analysis concentration: 103 ppm (RSD = 2.7%)

Sampler analysis: No detectable n-Hexane in any sampler.

(estimated LOD = 1.5 micrograms, equivalent to 0.125 ppm)

Conclusion: Packaging will prevent contamination of stored samplers.

[⋄] Based on 111.6% desorption efficiency

Scope of the Method

Acetone **Analyte:** Matrix: Air Procedure: Adsorption on a 575-002 SKC passive sampler, desorption with 2 ml of CS₂, and analysis by GC-FID. **Sampling Rate:** 15.2 ml/min valid for PEL samples from 1 to 8 hours 20.3 ml/min valid for STEL samples less than 1 hour **Exposure Guidelines:** ACGIH-TLV (1994/95) 750 ppm TWA, 1000 ppm STEL 750 ppm TWA, 1000 ppm STEL OSHA (1995) NIOSH (1995) 250 ppm TWA Validation Range, Recovery: Compound Validation Range ppm in air Mean % Recovery Acetone 75-1500 90.2 (High humidity) **Detection Limits:** 0.1 PEL concentration was easily determined. No studies were made to determine the absolute detection limit. **Temperature Effects:** Samples could be taken from 10° C to 40° C. **Factorial:** No significant effects were found due to the interaction of factors that affect sampling accuracy. **Humidity Effects:** Use 94.1% recovery for humidity below 50% RH and 90.2% above 50% RH. **Storage Effects:** The passive sampler can store for at least 14 days at freezer temperatures (-8° C) with no loss in recovery. Precautions must be taken at ambient temperatures. Average loss after 14 days at room temperature was 12.5%. Do not store at room temperature. **Interferences:** Any compound that has the same retention time as Acetone will interfere with the analysis. A study was also conducted where passive samplers were exposed to 100 ppm toluene and 1500 ppm Acetone and no significant loss in recovery was observed. November 1992 **Validation Completion Date: Physical Properties:**

Boiling Pt. at 760 mm Hg

56.2° C

10

Mol. Weight (g/mole)

58.08

Publication No. 1303 Rev 230825

Acetone

Density (g/ml)

0.7899

Background

History of Methodology

Previous methodologies have used activated charcoal SKC Lot 120 in a sample tube, or there is a newer method which uses carbon molecular sieve in a sample tube.

Research Purpose

The present work was to evaluate and validate the SKC 575 Series passive sampler containing Anasorb 747 as a method for sampling Acetone. The passive sampler was validated over a concentration range of 0.1 to 2 x PEL. Critical parameters such as analytical recovery, concentration, relative humidity, reverse diffusion, storage stability, temperature, sampling time, wind speed and orientation, and the presence of interfering compounds were addressed.

Experimental

Optima-grade Acetone (Fisher Scientific) was used. The HPLC-grade carbon disulfide (99.9%) was obtained from Aldrich Chemical Company. The 575 passive sampler containing Anasorb 747 (SKC Cat. No. 575-002) and the Anasorb 747 tubes used for atmosphere calibrations (SKC Cat. No. 226-81) are available from SKC, Inc.

A dynamic atmosphere generation apparatus was used to generate precise concentrations of Acetone in air for exposure of the passive samplers. The system is described in Appendix A and Figure 1. The atmosphere was fed into an exposure test chamber. The passive samplers were exposed on a rotating bracket inside the test chamber to simulate wind velocity and orientation.

Analytical recoveries for the passive samplers were conducted by injecting a known amount of Acetone (as a CS₂ solution) into the back of each sampler. The passive samplers were capped, allowed to equilibrate overnight, and analyzed the next day to determine analytical recovery or desorption efficiency. The tests were conducted at mass loadings equivalent to an 8-hour time weighted average sample (7.76 L at the expected sampling rate of 16.2 ml/min) at 0.1, 0.5, 1.0 and 2.0 PEL under dry conditions. A wet desorption efficiency was conducted by first exposing the passive sampler to 80% RH air for eight hours and then spiking the passive sampler at a mass loading equivalent to the 1 PEL (750 ppm) level. These passive samplers were all equilibrated overnight and analyzed the next day. Because of a significant difference between the "dry" and "wet" results, the desorption efficiency was repeated on pre-humidified passive samplers for all levels.

The sampling rate, reverse diffusion and storage stability experiments on the passive sampler were conducted under dynamic conditions in the test chamber described above. In the storage stability study, recovery is referred back to the reference samples analyzed on Day 1.

The passive samplers were desorbed (in situ) with 2 ml of CS₂ and shaken on a flatbed shaker for 30 minutes. All extracts were transferred to autosampler vials and analyzed by flame ionization gas chromatography. A chromatogram with analytical conditions is shown in Figure 2.

Sampling Rate Determination

Sampling rates can be determined by one of several statistical methods from the experimental data and they differ by only a small amount. Any bias taken is toward the protection of the worker.

We use the time-weighted average from one to eight hours where results fall within NIOSH criteria.

We constantly review our data and conduct experimental work to provide the most precise sampling rate. This rate may differ slightly from previously published sampling rates. Use the rate listed in this report.

11

Analytical Recovery

NIOSH Requirements

Experimental Design

Interpretation of Results

Spike 16 samplers, 4 at each of 4 concentration levels (0.1, 0.5, 1.0 & 2.0 x STD) Equilibrate about 12 h and analyze.


For the 3 higher levels require $\geq 75\%$ recoveries with $S_r \leq 0.1$.

Results			"D	ry" Spikes	S^1	
	PEL Level	Spike (mg)	Recovery (mg)	Recovery %	Mean	RSD %
	0.1	1.393	1.056	75.8		
			1.098	79.0		
			1.097	78.8		
			1.170	84.0	79.4	3.4
	0.5	7.069	7.131	100.9		
			7.254	102.6		
			7.180	101.6		
			7.154	101.2	101.6	0.7
	1.0	13.823	13.00	94.0		
			12.94	93.6		
			13.15	95.2		
			12.94	93.6	94.1	0.0
	1.5	20.735	19.86	95.8		
			20.40	98.4		
			20.50	98.9		
			20.09	96.9	97.5	1.4
	2.0	27.646	27.05	97.8		
			26.77	96.8		
			27.09	98.0		
			27.24	98.5	97.8	0.7
			Ove	rall Mean	94.1	9.2

Pooled mean (all levels) 94.1% RSD 8.6% Used in low humidity factorial experiments

Pre-humidified ¹					
Recovery (mg)	Recovery %	Mean	RSD %		
1.223	87.8				
1.229	87.8				
1.188	85.3				
1.249	89.7	87.8	2.1		
6.113	86.5				
6.111	86.5				
6.247	88.4				
6.161	87.2	87.1	1.0		
12.87	93.1				
13.02	94.1				
12.73	92.1				
12.80	92.6	93.0	1.0		
19.49	94.0				
19.07	92.0				
19.28	93.0				
19.22	92.7	92.9	0.9		
27.36	99.0				
27.48	99.4				
26.56	96.1				
26.16	94.6	97.3	2.4		
Ove	rall Mean	91.6	4.6		

Pooled mean (all levels) 91.6% RSD 4.5% Assuming 2.0 x PEL to be an outlier, overall mean = 90.2% RSD 3.4%. Used in all experiments at 80% RH



¹ See Analytical Recoveries on p. 11 for explanation.

Sampling Rate and Capacity

NIOSH Requirements

Experimental Design


Expose samplers (4 per time period) for 1/8, 1/4, 1/2, 1, 2, 4, 6, 8, 10 and 12 h to 2 x STD, 80% RH and 20 cm/s face velocity. Plot concentration vs. time exposed. Determine MRST and SRST.


Interpretation of Results

Verify sampling rate. State useful range at 80% RH and 2 x STD. Capacity - sample loading corresponding to the downward break in conc. vs time curve from constant concentration. SRST-time linear uptake rate achieved. MRST - 0.67 x capacity (1 analyte)
MRST-0.33 x capacity (Multi-analyte)

Results

Itesuits					
Time (hrs)	Uptake (mg)	Mean (mg)	RSD%	DE Corr (mg)	Concn. (ppm)
0.125	0.562	(8/		(8)	(PPIII)
******	0.563				
	0.533				
	0.562	0.555	2.6	0.615	2267
0.25	0.970				
	0.944				
	0.955				
	0.959	0.957	1.1	1.061	1956
0.5	1.959				
	1.830				
	1.832				
	1.777	1.849	4.2	2.050	1889
1	3.418				
	3.448				
	3.453				
	3.555	3.469	1.7	3.845	1772
2	6.783				
	6.037				
	6.869				
	6.620	6.577	5.7	7.292	1680
4	12.532				
	12.781				
	12.309	12 10 5	4.0	12.012	4.50.5
	12.322	12.486	1.8	13.843	1595
6	17.479				
	17.360				
	18.223	17 (00	2.4	10.501	1.400
	17.372	17.608	2.4	19.521	1499
8	23.604				
	22.054				
	22.164 22.649	22.618	3.1	25.075	1444
10		22.016	3.1	23.073	1444
10	26.267 27.564				
	25.932				
	27.789	26.888	3.4	29.089	1374
12	30.880	20.000	J. T	27.007	13/7
12	30.538				
	29.900				
	30.260	30.394	1.4	33.698	1294
	30.200	30.37 T		23.070	1271





Concentration values are calculated using the 1- through 8-hour time-weighted average sampling rate of 15.2 ml/min based on a standard atmosphere of 1527 ppm.

13

Reverse Diffusion

NIOSH Requirements

Experimental Design

Expose 20 samplers to 2 x STD 80% RH for $0.5~\rm x$ MRST. Remove and analyze 10 samplers. Expose others to 80% RH and no analyte for remainder of MRST.

Interpretation of Results

Require \leq 10% difference between means of the two sampler sets at the 95% CL.

Results (in milligrams)

Exposed 4 hours to analyte	Exposed 4 hours to analyte plus 4
	hours at zero analyte concentration

Uptake	DE Corr.	Uptake	DE Corr.
<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>
12.603	13.973	13.419	14.877
13.307	14.753	13.308	14.754
12.963	14.372	12.826	14.219
11.858	13.146	13.412	14.869
12.498	13.857	12.524	13.885
12.157	13.478	12.436	13.787
12.540	13.903	12.327	13.666
12.313	13.652	12.837	14.232
12.499	13.857	13.382	14.836
12.566	13.931	13.502	14.969
Mean:	13.892		14.409
SD:	0.443		0.508
RSD:	3.2%		3.5%

The difference between the two sets of results is less than 10%.

Storage Stability

NIOSH Requirements

Experimental Design

Expose 3 sets of samplers (10 per set) at 80% RH, 1 x STD, and 0.5 x MRST. Analyze first set within 1 day, second set after 2 weeks storage at about 25° C, third set after 2 weeks storage at about 5° C.

Interpretation of Results

Require \leq 10% difference at the 95% CL between means of stored sampler sets and set analyzed within 1 day.

Results (in milligrams)

	Day 1 (I	Room Temp)	Day 14 (R	oom Temp)	Day 1	4 (4°C)
	Uptake	DE Corr.	Uptake	DE Corr	Uptake	DE Corr.
	<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>
	6.029	6.683	5.345	5.926	6.060	6.718
	6.244	6.923	5.287	5.861	5.539	6.141
	6.045	6.702	5.228	5.797	5.526	6.126
	5.933	6.578	5.125	5.682	5.371	5.955
	5.578	6.184	5.116	5.671	5.703	6.323
	6.099	6.762	5.227	5.795	5.974	6.623
	6.076	6.736	5.253	5.824	5.885	6.525
	5.978	6.628	5.407	5.994	5.715	6.336
	6.007	6.660	5.264	5.836	6.223	6.899
	6.130	6.796	5.375	5.959	5.828	6.462
Mean:		6.665		5.835		6.411
SD:		0.1945		1.1070		0.2922
RSD:		2.9%		1.8%		4.6%

There is no significant loss of sample on refrigerated storage.*

^{*} Samplers stored at room temperature lost 12.5% compared to Day 1. The observed difference (0.829 mg) is slightly greater than the 95% confidence interval test difference of 0.814 indicating a loss significantly greater than 10%.

Factorial Results

NIOSH Requirements

Experimental Design

Test the following factors at the levels shown. Use a 16 run fractional factorial design (4 samplers per exposure) to determine significant factors.

Factor Test Levels
analyte concentration 0.1 & 2 x STD
exposure time SRST & MRST
face velocity 10 & 150 cm/s
relative humidity 10 & 80% RH
interferant 0 & 1 x STD
sampler orientation parallel &

perpendicular (to air flow)

Interpretation of Results

Indicate any factor that causes a statistically significant difference in recovery at the 95% CL. Investigate further to characterize its effect.

Results (in micrograms per ppm per hour (µg ppm⁻¹ h⁻¹), desorption efficiency corrected)

<u>Run #</u>	<u>Ind</u>	<u>lividual Monit</u>	tor Results		<u>Average</u>	<u>%RSD</u>
1	1.7576	1.7411	1.8119	1.7338	1.7611	2.0
2	2.4315	2.2720	2.3414	2.2257	2.3177	3.9
3	1.9812	2.1448	1.9077	Δ	2.0112	6.0
4	2.3223	2.2870	2.2449	2.3115	2.2914	1.5
5	Δ	2.0938	2.1046	2.0415	2.0800	0.1
6	2.5277	2.5553	2.5896	2.5592	2.5579	1.0
7	Δ	1.7604	1.6223	1.7796	1.7208	5.0
8	2.0774	2.1438	2.1236	2.2079	2.1382	2.5
9	2.0203	2.1030	1.9831	2.1336	2.0600	3.4
10	1.6228	1.6386	1.6023	1.6524	1.6290	1.3
11	1.6197	1.6781	1.6644	1.7489	1.6778	2.1
12	Δ	2.6836	2.4917	2.4497	2.5417	4.9
13	2.6367	2.5688	2.5930	Δ	2.5995	1.3
14	1.9454	1.8043	1.8290	1.7729	1.8380	4.1
15	2.4028	2.3560	2.2770	2.4546	2.3726	3.2
16	2.4109	2.1519	2.2822	2.2417	2.2717	4.7

Notes: Low face velocity = 20 cm/sLow concentration = 0.1 PEL

Minimum sample time = 1 hour

Toluene used in the interference experiments.

^a Outlier result not used, average of group substituted for statistical calculations.

Factorial Summary

Run Num	<u>ber</u>	<u>μg</u> /]	ppm/hour
Run#	1	=	1.7611
Run#	2	=	3.2177
Run#	3	=	2.0112
Run#	4	=	2.2914
Run#	5	=	2.0800
Run#	6	=	2.5579
Run#	7	=	1.7208
Run#	8	=	2.1382
Run#	9	=	2.0600
Run#	10	=	1.6290
Run#	11	=	1.6778
Run#	12	=	2.5417
Run#	13	=	2.5995
Run#	14	=	1.8380
Run#	15	=	2.3726
Run#	16	=	2.2717
Avera	ge	=	2.1168 = 14.9 ml/min

	Factor	Effect	Percent	Significance
A -	Concentration	0.27	12.8%	N.S.
В -	Relative Humidity	-0.16	7.6%	N.S.
C -	Interferants	-0.13	6.2%	N.S.
D -	Time	-0.29	13.5%	N.S.
E -	Face Velocity	0.17	8.0%	N.S.
F -	Orientation	-0.08	4.0%	N.S.
E1 -	ABC	0.11	5.0%	N.S.
E2 -	ABD	-0.01	0.7%	N.S.
E3 -	AB + EF	0.20	9.6%	N.S.
E4 -	AC + DF	-0.15	7.3%	N.S.
E5 -	AD + CF	0.02	1.1%	N.S.
E6 -	AE + BF	0.16	7.6%	N.S.
E7 -	CD + BE	-0.05	2.5%	N.S.
E8 -	BC + DE	-0.17	7.8%	N.S.
E9 -	BD + CE	0.16	7.7%	N.S.

Minimum Significant Effect (MSE) = ± 0.30

No significant effect of factors or their tested interactions.

Temperature Effects

NIOSH Requirements

Experimental Design

Expose samplers (10 per temp) to 0.5 x STD at 10, 25, & 40° C for 0.5 x MRST.

Interpretation of Results

Define temperature effect and verify correction factor, if provided.

Results (in milligrams)

10 ° C			25 ° C		40° C		
Uptake	DE Corr.	Uptake	DE Corr	Uptake	DE Corr.		
<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>	<u>(mg)</u>		
6.739	7.471	6.803	7.543	6.661	7.385		
7.001	7.762	6.971	7.728	6.552	7.264		
7.151	7.928	6.788	7.526	6.943	7.697		
6.970	7.727	6.767	7.502	7.042	7.807		
7.340	8.137	6.480	7.184	6.866	7.612		
7.131	7.906	6.791	7.529	7.042	7.807		
7.019	7.782	6.997	7.757	6.753	7.486		
6.914	7.665	6.561	7.273	7.158	7.936		
7.163	7.941	6.910	7.661	6.703	7.431		
7.156	7.933	6.633	7.354	6.566	7.279		
Mean:	7.825		7.506		7.570		
RSD:	2.4%		2.5%		3.1%		
Concentration: ¹	750.0		750.1		696.3		
Uptake rate: ²	2.608		2.502		2.718		
Theoretical: ³	2.439				2.565		

Uptake is within 10% of theoretical (based on 25° C result) at both 10° C and 40° C.

 $^{^{1}}$ In ppm at the sampling temperature. 1 x STD used for more rigorous test

² Uptake rate measured as micrograms/ppm (sampling temperature)/hour (µg ppm ⁻¹ h⁻¹)

³ Theoretical uptake rate is based on 25° C result

Accuracy and Precision

NIOSH Requirements

Experimental Design

Calculate precision and bias for samplers (10 per conc. level) exposed to 0.1, 0.5, 1 & 2 x STD at 80% RH for \geq MRST. Use data from previous experiments.

Interpretation of Results

Requires bias within \pm 25% of true value at 95% CL with precision S_r \leq 10.5% for 0.5, 1 & 2 x STD levels.

All Values in µg/ppm/hr

Monitors run at 2.0 X PEL			Monitors run at 1.0 x PEL						
Values for individual monitors for the			Values for	Values for individual monitors for the					
Rate/Capacity Experiment			Storage Stability Experiment						
				Day 1 -	2.2777	2.3077	2.2340	2.1927	2.0947
4 Hour - 2.0887	2.1302	2.0515	2.0537		2.2540	2.2453	2.2093	2.2200	2.2653
6 Hour - 1.9421	1.9289	2.0248	1.9302	R.T	1.9753	1.9537	1.9323	1.8940	1.8903
8 Hour - 1.9670	1.8378	1.8470	1.8874		1.9317	1.9413	1.9980	1.9453	1.9863
				5 deg -	2.2393	2.0470	2.0420	1.9850	2.1077
Values for individual monitors for the			_	2.2077	2.1750	2.1120	2.2997	2.1540	
Reverse Diffusion I	Experiment								
•			Values for individual monitors for the						
4 Hour - 2.3288	2.4588 2.3	3953 2.191	10 2.3095	Temperature Effects Experiment					
2.2463	2.3172 2.3	2753 2.309	2.3218	10 deg -	2.5526	2.6520	2.7087	2.6401	2.7801
8 Hour - 2.4795	2.4590 2.3	3698 2.478	32 2.3142	_	2.7023	2.6586	2.6189	2.7132	2.7104
2.2978	2.2777 2.3	3720 2.472	27 2.4948	25 deg -	2.5140	2.5757	2.5083	2.5003	2.3943
					2.5093	2.5853	2.4240	2.5533	2.4510
Values for individual monitors for the			40 deg -	2.5852	2.5429	2.6944	2.7330	2.6647	
Factorial Experimen	nt			_	2.7330	2.6206	2.7781	2.6013	2.5481
•									
Run #2 - 2.4315	2.2720	2.3414	2.2257	Monitors run at 0.1 x PEL					
Run #4 - 2.3223	2.2870	2.2449	2.3115	Values for	individual	monitors	for the		
Run #13 - 2.6367	2.5688	2.5930	2.5995	Factorial E	xperiment				
Run #15 - 2.4028	2.3560	2.2770	2.4546	Run #1 -	-	1.741	1 1.8	119 1	.7338
				Run #3 - 1.9812 2.1448 1.9077 2.0112					
				Run #14 -	1.9454	1.804	3 1.8	290 1	.7729
				Run #16 -	2.4109	2.151	9 2.2		.2417

$Summary \qquad \qquad Average \ Values \ in \ \mu g/ppm/hr$

	Relative Standard	Degrees of	Experiment	<u>Average</u>	RSD
0.1 1.0 2.0	Deviation 4.3% 3.0% 3.0%	Freedom 12 54 39	Rate/Capacity Reverse Diffusion Factorial, 2 PEL Storage Stability Temperature	1.9741 2.3585 2.3953 2.1023 2.6084	2.4% 3.4% 2.6% 3.2% 2.7%
			Factorial 0.1 PEL	1.9705	4.3%
			Overall average Overall sampling ra	2.2838 te = 16.0 ml/min \pm	3.1% 1.0 ml/min

Publication No. 1303 Rev 230825

Acetone

Appendix A

Atmosphere Generation Apparatus

The instrument is designed to expose a known concentration of a chemical hazard to a passive sampler under controlled conditions of: 1. Concentration, 2. Temperature, 3. Humidity, 4. Wind Velocity Effect, 5. Time, and 6. Up to four multicomponent hazards.

Description

The instrument consists of:

- 1. an exposure chamber in which the wind velocity effects are controlled by internal rotating holders,
- 2. an air supply and purification train such that dry air is blended with saturated air under desired temperature conditions so as to provide air at a known flow and selectable humidity,
- 3. an injection system composed of precision motor driven syringes in which 1 to 4 chemical hazards can be injected into the flow system and in which the temperature of the injectors is closely controlled,
- 4. an electrical control system that controls the entire instrument operation,
- 5. the chamber concentration can be verified by either solid sorbent sampling tubes actively sampled or by gas analysis of the gas phase. The particular verification method used will depend on the analyte of interest.

Means are also included to check the relative humidity.

20

Figure 1
Atmosphere Generation Apparatus





Figure 2 Analytical Instrument

Sample Chromatogram Acetone in CS_2



Abbreviations

C Celsius

CL confidence level

cm centimeter
ml milliliter
min minute
g gram

GC-FID gas chromotography - flame ionization detector

h hourL liter

LOD limit of detection

MRST maximum recommended sampling time

N.S. not significant

PEL permissible exposure limit

RH relative humidity
TLV threshold limit value
TWA time-weighted average
RSD relative standard deviation

SD standard deviation

SRST shortest recommended sampling time

STD the appropriate exposure standard (OSHA PEL, ACGIH TVA, or NIOSH recommended

standard)

S second

S_r Pooled relative standard deviation

V volume

Trademarks

Anasorb is a registered trademark of SKC Inc.

Tedlar is a registered trademarik of DuPont Corporation.

Porapak is a registered trademark of Waters Associates, Inc.

References

- 1. Cassinelli, M.E., Hull, R.D., Crable, J.V. and Teass, A.W., "Diffusive Sampling: An Alternative to Workplace Air Monitoring," A. Berlin, R.H. Brown and K.J. Saunders (Royal Society of Chemistry, London) (eds.), NIOSH Protocol for the Evaluation of Passive Monitors, 1987: p 190-202.
- 2. Brown, R.H., Harvey, R.P., Purnell, C.J., and Saunders, K.J., "A Diffusive Sampler Evaluation Protocol." Am. Ind. Hyg. Assoc. J. 45:67-75 (1984).
- 3. CEN/TC137/WG2 (1993) EN 482. Workplace Atmospheres General Requirements for the Performance of Procedures for the Measurement of Chemical Agents. Comité Européen de Normalisation, Brussels, Belgium.
- 4. CEN/TC137/WG2 (1995) prEN 838. Workplace Atmospheres Diffusive Samplers for the Determination of Gases and Vapours Requirements and Test Methods. Comité Européen de Normalisation, Brussels, Belgium.
- 5. Guild, L.V., Myrmel, K.H., Myers, G. and Dietrich, D.F., "Bi-Level Passive Monitor Validation: A Reliable Way of Assuring Sampling Accuracy for a Larger Number of Related Chemical Hazards," Appl Occup Environ Hyg, Vol 7, No. 5, May 1992, pp. 310-317.
- 6. Harper, M., Fiore, A.A., Fiorito, D.L. and O'Lear, C., "Comparison of the Tests for Non-ideal Behaviour by Reverse Diffusion in the NIOSH and CEN Diffusive Sampler Evaluation Protocols," Submitted to Ann. Occup. Hyg. (1995).
- 7. Harper, M., Guild, L.V., "Levels of Validation Experience in the Use of the NIOSH Diffusive Sampler Evaluation Protocol," Submitted to Am. Ind. Hyg. Assoc. J. (1995).

24